VSO[®] Miniature Proportional Valve Thermally Compensated Proportional Valve



Typical Applications

- Gas Chromatography
- Mass Spectrometry
- Ventilators
- O₂ Concentrators/Conservers
- Anaesthesia Delivery & Monitors
- Pressure & Flow Control
- Mass Flow Control

Physical Properties

Valve Type:

2-Way Normally Closed

Media:

Air, argon, helium, hydrogen, methane, nitrogen, oxygen, & others

Operating Environment:

32 to 131°F (0 to 55°C)

Storage Temperature:

-40 to 158°F (-40 to 70°C) Length:

1.79 in (45.3 mm)

Width:

0.63 in (15.9 mm)

Height:

0.67 in (17.0 mm)

Porting:

1/8" (3 mm) barbs or 10-32 female; manifold mount (available with screens)

Weight:

2.2 oz (63 g)

The VSO® miniature proportional valve provides enhanced flow control for applications where precise control flow control is required up to 56 slpm. The VSO® miniature proportional valve provides precise flow control of gas in proportion to input current. The valve can be controlled with either DC current or pulse width modulation along with closed loop feedback to deliver optimal system performance. Together with its ability to provide precise control over varying temperatures and media types, the VSO® miniature proportional valve is ideally suited for manufacturers of medical and analytical equipment.

Features

- Enables precise flow control for improved instrument accuracy
- Thermally compensated to maintain precise flow over a wide range of media
- Computer automated calibration and serialization for performance traceability
- Cleaned for Oxygen and Analytical Service use
- Proven performance tested to 100 million life cycles
- RoHS compliant 🗸

Physical Properties

Internal Volume:

0.031 in³ (0.508 cm³) **Filtration:** (Suggested and Available) Models 1 & 2: 17 micron Models 3, 4, 5, & 6: 40 micron

Flow Direction:	
Inlet Port	Port 2
Outlet Port	Port 1

Electrical

Power: 2.0 Watts maximum

Voltage:

See Table 2 Electrical Termination:

18" (45.7 cm) Wire Leads, PC Mount, Quick Disconnect Spade

Wetted Materials

Series 11 Body: 360 HO, Brass

Series 25 Body:

Nickel-Plated Brass

Stem Base:

430 FR Stainless Steel and Brass 360 HT

All Others: FKM; FFKM; 430 FR Stainless Steel; 300 Series Stainless Steel

Performance Characteristics

Leak Rate:

The leakage shall not exceed the following values: Internal 0.2 SCCM of He with a differential pressure of 1 psid,

25 psid and 150 psid

External 0.016 SCCM of He at 150 psi

Pressure:

0 to 50 psi (3.45 bar) 0 to 75 psi (5.17 bar) 0 to 100 psi (6.89 bar) 0 to 150 psi (10.34 bar) See Table 1

Vacuum:

0-27 in Hg (0-686 mm Hg)

Orifice Sizes:

0.010 in (0.25 mm) 0.020 in (0.51 mm) 0.030 in (0.76 mm) 0.040 in (1.02 mm) 0.050 in (1.27 mm) 0.065 in (1.65 mm)

Hysteresis:

7% of full scale current (Typical) 15% of full scale current (Max)

VSO is a registered trademark of Parker Hannifin Corporation.





Typical Air Flow with 20 VDC Coil @ 25psid (1.7 bar) All Models

Table 1: Pressure and Flow Capabilities

Orifice Diameter	Maximum Operating Inlet Pressure	Maximum Operating Pressure Differential		
0.010 in (0.25 mm)	150 psig (10.34 bar)	150 psid (10.34 bar)		
0.020 in (0.51 mm)	150 psig (10.34 bar)	150 psid (10.34 bar)		
0.030 in (0.76 mm)	150 psig (10.34 bar)	150 psid (10.34 bar)		
0.040 in (1.02 mm)	150 psig (10.34 bar)	75 psid (5.17 bar)		
0.050 in (1.27 mm)	150 psig (10.34 bar)	100 psid (6.89 bar)		
0.065 in (1.65 mm)	150 psig (10.34 bar)	50 psid (3.45 bar)		



h (Cr











Coil Type: Quick Connect Spade



*PCB Pin Layout (Coil Type 4 PC Pin)





Minimum Available Voltage (VDC)	Nominal Coil Resistance @ 20°C (Ohms)	Input Current for Full Flow (mA)	
5.5	11	304	
8.0	23	212	
11.5	47	152	
13.5	68	125	
20.0	136	91	
29.0	274	66	
41.0	547	47	
56.0	1094	32	

Table 2: Electrical Requirements

VSO® Installation and Use

Typical Valve Set-up



Valve Electrical Control

Basic Control:

The VSO[®] valve can be controlled by either voltage or current; however, it is highly recommended that current control be employed to ensure the most repeatable valve flow performance.

PWM Control:

For PWM control, the signal applied to the valve should have a frequency between 5-12kHz. Optimum frequency will be application dependent.





Suggested VSO[®] Current Driver Schematic

This simple current driver circuit draws only 1 mA at the input control (0-5VDC) and provides control for any VSO® valve configuration regardless of valve voltage or resistance.

Table 3 (below) describes the recommended R1 and R2 resistor values based upon the full shut-off current.

Table 3: Selectable Resistor Values for a Low Current (1 mA) LM358-Based Current Driver

Minimum Available Voltage (VDC)	Valve Drive Voltage (VDC)	Nominal Coil Resistance @ 20°C (Ohms)	Input Current for Full Flow (mA)	R1 (Ohms)	R2 (Ohms)
5.5	7.5	11	304	5100	330
8.0	10.0	23	212	4990	221
11.5	13.5	47	152	5100	160
13.5	15.5	68	125	4420	113
20.0	22.0	136	91	4420	82
29.0	31.0	274	66	4990	66.5

Manifold & O-Ring Dimensions & Design Not shipped with valves.



O-RING DIMENSIONS

O-RING DIMENSIONS

- I.D. = \emptyset .114 ±.005 [\emptyset 2.90 ±0.13]
- W = .070 ±.003 [1.78 ±0.08] O.D. = Ø.254 [Ø6.45] REFERENCE





Accessories

Screw 4-40 x 5/8" Pan Head, Phillips

191-000115-010 (2 required for each valve)

O-Ring (Manifold Seal) Dimensions

190-007024-002 (2 required for each valve)

I.D. = Ø.114 ±.005 [Ø2.90 ±0.13] W = .070 ±.003 [1.78 ±0.08] O.D. = Ø.254 [Ø6.45] REFERENCE

"W"

Ordering Information

ample Part ID	VSONC	1	s	11	v	А	F	8
Description	Standard	Model Number: Maximum Operating Pressure / Orifice Size	Series	Body Series	Elastomer/ Body Material	Coil Voltage/Coil Resistance/Coil Current*	Electrical Interface	Pneumatic Interface
Options		1: 150 psi / 0.010° (0.25 mm) 2: 150 psi / 0.020° (0.51 mm) 3: 150 psi / 0.030° (0.76 mm) 4: 75 psi / 0.040° (1.02 mm) 5: 100 psi / 0.060° (1.27 mm) 6: 50 psi / 0.065° (1.65 mm)		11: Series 11 25: Series 25	V: FKM / Brass C: FFK/ / Brass I: FFKM / Stainless Steel H: FKM / Stainless Steel	A: 5.5 VDC / 11 Ohm / 0.304 Amp B: 8 VDC / 23 Ohm / 0.212 Amp C: 11.5 VDC / 47 Ohm / 0.152 Amp D: 13.5 VDC / 68 Ohm / 0.125 Amp F: 20 VDC / 136 Ohm / 0.031 Amp F: 29 VDC / 274 Ohm / 0.066 Amp * Maximium voltage for continuous full flow, ambient temperture 55 °c	F: Wire Leads, 18° (45.7 cm) P: PC Board Mount, 4 Pin Q: Quick Connect, Spade	0: Manifold Mount 1: Manifold Mount w/screens 5: 10-32 Threaded Female (Series 2 8: 1/8° (3 mm) Barbs
•								
Accessories								

190-007024-002: O-ring, FKM, 0.114" ID x 0.070" Thick* 191-000115-010: Screw 4-40 x 5/8" Pan Head ** * Not supplied with the valve. Used as a seal between the valve body and manifold **Not supplied with the valve. Used to mount the valve to a manifold.



NOTE: In order to provide the best possible solution for your application, please provide the following requirements when contacting Applications Engineering:

- Media, Inlet & Outlet Pressures
- Minimum Required Flow Rate
- System Supply Voltage
- Media & Ambient Temperature Range

Please click on the Order On-line button (or go to www.parker.com/precisionfluidics/vso) to configure your VSO® Thermally Compensated Proportional Valve. For more detailed information, visit us on the Web, or call and refer to VSO® Series 11 Performance Spec. #790-002115-001 and Drawings #890-003022-001 and #890-003022-003. VSO® Series 25 Performance Spec. #790-002115-001 and Drawing # 890-003023-001.

PPF-MPV-002/US September 2012

